

# Symbol Ls 2208 Quick Start Guide

## Introduction to the Symbol LS2208 Barcode Scanner

The **Symbol LS2208 Quick Start Guide** is the essential document that helps users get their handheld barcode scanner up and running with minimal frustration. Manufactured by Zebra Technologies (formerly Symbol Technologies), the LS2208 is one of the most reliable and widely used single-line laser barcode scanners in retail, healthcare, and warehouse environments. Its rugged design, fast scanning speed, and straightforward integration make it a favorite among small businesses and large enterprises alike. However, even the most user-friendly devices can cause confusion if you skip the setup steps. A proper quick start ensures that the scanner functions correctly with your point-of-sale (POS) system, inventory software, or computer. This article walks you through everything you need to know about the Symbol LS2208 Quick Start Guide, from unboxing to advanced configuration tips.

Whether you are a beginner or an experienced IT professional, understanding how to quickly configure the LS2208 will save you time and reduce the risk of scanning errors. The quick start guide provided by Zebra typically includes a series of programming barcodes that you can scan to change settings such as baud rate, interface type, and data formatting. Because the scanner stores configuration in non-volatile memory, you only need to set it up once. Below, we will cover the physical setup, basic configuration, troubleshooting, and best practices for maintaining your LS2208 scanner.

## Unboxing Your Symbol LS2208

Before diving into the **Symbol LS2208 Quick Start Guide**, let us review what you should find inside the box. A standard package includes:

- One Symbol LS2208 handheld barcode scanner
- A detachable interface cable (typically USB or RS-232, depending on the model)
- A printed quick start guide (or a reference card with programming barcodes)
- A power supply (for RS-232 models, USB-powered models may not include one)
- Mounting bracket and screws (optional in some packages)

Ensure that all components are present before proceeding. If you are using the scanner with a USB connection, you can usually power it directly from the computer. For serial or RS-232 connections, you will need the external power supply. The quick start guide will show you which interface cable to use and how to connect it securely.

## Physical Setup: Connecting the Scanner to Your Host

### Step 1 - Choose the Correct Interface Cable

The LS2208 supports several interfaces: USB (keyboard emulation, HID, or serial emulation), RS-232 serial, and IBM 46xx. The **Symbol LS2208 Quick Start Guide** emphasizes that you must use the cable matching your host device. For most modern computers, a USB cable is the simplest option. To connect:

1. Insert the modular plug (usually RJ-45 or RJ-50 style) into the scanner's base.
2. Connect the other end to your computer's USB port or serial port.
3. If using RS-232, plug in the power supply and connect to your host.

### Step 2 - Power On and Verify Connection

When you connect the scanner, it will emit a short beep and the LED will flash red momentarily, then turn green. A steady green light indicates that power is active. If the LED does not illuminate, check the cable connection and power source. The quick start guide includes a "scan test" barcode – scanning it will confirm that the scanner is communicating with your host. Point the scanner at a barcode, pull the trigger, and listen for a beep. If you see the barcode data appear on your screen, the setup is successful.

## Understanding the Quick Start Guide's Programming Barcodes

The heart of the **Symbol LS2208 Quick Start Guide** is a set of configuration barcodes. These barcodes allow you to change the scanner's behavior without needing a separate utility program. Common settings include:

- **USB Keyboard Emulation:** Makes the scanner act like a keyboard, typing the barcode data into any application.
- **Adding a Suffix:** Append a carriage return (Enter) or tab after each scan.
- **Data Editing:** Remove or add leading characters.
- **Baud Rate (for serial models):** Set communication speed to match your host.

To change a setting, you simply scan the appropriate "Enter Configuration" barcode, then scan the specific settings barcode, and finally scan the "Exit Configuration" barcode. The guide also includes "factory defaults" barcode to reset the scanner to its original state.

### Example: Adding a Carriage Return Suffix

If you want each scanned barcode to automatically end with an Enter keypress (e.g., for spreadsheet data entry), locate the

“Suffix” section in the quick start guide. Scan the “Enter Configuration” barcode, then scan “CR (Carriage Return)”, then scan “Exit Configuration”. The scanner will beep twice to confirm. This is a standard configuration described in nearly every **Symbol LS2208 Quick Start Guide**.

## Common Scenarios and Configuration Tips

---

### Setting Up for USB Keyboard Emulation

Most users will want the scanner to work immediately after plugging it in. By default, USB models are set to keyboard emulation. However, if you have used the scanner with a different host previously, you may need to re-enable this mode. The quick start guide lists a barcode labeled “USB Keyboard Emulation”. Scan it after entering configuration mode, and the scanner will behave as a standard keyboard. This is especially useful for POS systems or inventory management software that expects keyboard input.

### Changing the Interface Type

If you move your LS2208 from a USB computer to a serial terminal, you must change the interface setting. The quick start guide provides separate barcodes for USB, RS-232, and IBM 46xx. Simply scan the one that matches your new host. Without this step, the scanner may not transmit data correctly. Always confirm the interface type is correct – the guide typically has a “Verify” barcode that shows current settings.

### Data Formatting: Removing Leading Zeros or Custom Prefixes

Occasionally, you may need to strip certain characters from the start of a barcode. The quick start guide includes advanced data editing barcodes. For example, to remove the first three characters, you would scan “Enter Configuration”, then “Data Format”, then specify the number of characters to remove, then “Exit Configuration”. While the quick start guide does not include all advanced options (those are in the full product reference guide), the most common edits are covered. You can also invert the scanner’s read direction or enable scanning of specific symbologies like Code 128, Code 39, EAN-13, etc.

## Troubleshooting with the Quick Start Guide

---

### Scanner Does Not Beep When Triggered

If you pull the trigger and hear no sound, check the power connection first. Then, ensure the cable is firmly clicked into the scanner’s base. The **Symbol LS2208 Quick Start Guide** suggests scanning a “Test Barcode” to rule out a hardware issue. If the test barcode works but scanning real labels does not, the barcode symbology may be disabled. Scan the “Enable All Symbologies” barcode from the guide to allow reading most standard barcodes.

### Data Appears as Garbled Characters

Garbled text indicates a mismatch in data format or interface. For USB, make sure the scanner is in keyboard emulation mode, not serial emulation. For RS-232, verify baud rate, parity, and data bits match your host’s configuration. The quick start guide includes barcodes for common baud rates (9600, 19200, 38400). Scan the correct one and test again.

### Scanner Scans but No Data on Screen

This usually happens when the scanner is not recognized by your operating system. On Windows, open Device Manager and check under “Keyboards” or “Human Interface Devices”. If the scanner appears with a yellow exclamation mark, try a different USB port or reinstall the driver. The LS2208 USB driver is often built into modern OS, but for older systems, the quick start guide provides a link to Zebra’s support site. Scanning a barcode that switches the scanner to a different USB mode (e.g., HID POS) may also solve recognition issues.

## Maintenance and Best Practices

---

To keep your LS2208 performing optimally, follow these guidelines:

- **Clean the Scan Window:** Use a soft, lint-free cloth slightly dampened with water or a mild glass cleaner. Avoid abrasive materials that could scratch the laser aperture.
- **Store Properly:** When not in use, place the scanner in its stand or cradle. Do not drop or expose to extreme temperatures.
- **Avoid Cable Strain:** Ensure the cable is not tightly bent near the connector. A damaged cable can cause intermittent connection issues.
- **Update Configurations:** If you change your software environment, refer to the **Symbol LS2208 Quick Start Guide** again to update scanner settings. Resetting to factory defaults and reconfiguring is often safer than trying to modify an existing setup.

Regular firmware updates are rare for the LS2208, but Zebra occasionally releases new versions. Check their support website using the model number if you encounter compatibility issues with new barcode symbologies.

## Where to Find the Latest Quick Start Guide

---

If you have misplaced the printed copy, you can download the official **Symbol LS2208 Quick Start Guide** in PDF format from the Zebra Technologies Support Portal. Look for document number “p/n 72-122153-xx” which corresponds to the LS2208 series. The online version may include additional programming barcodes not present in the original printed card. Keep a digital copy on your

## Conclusion

---

The Symbol LS2208 barcode scanner remains a workhorse in data capture due to its simplicity, durability, and ease of setup. By following the **Symbol LS2208 Quick Start Guide**, you can avoid common pitfalls like incorrect interface selection, missing carriage returns, or disabled symbologies. Whether you are deploying a fleet of scanners in a retail chain or setting up a single unit for a home office, the guide provides all the essential configuration steps in a few barcode scans. Remember to always test with a known good barcode after making changes, and keep the guide handy for future adjustments. With proper setup and occasional maintenance, your LS2208 will deliver years of reliable scanning performance.